

STEP EIGHT

Shade Slat Assembly

1

Assemble shade slats by inserting the two slats into one joiner. Push firmly until extrusion bottoms out inside joiner. No screws are necessary.

Shade Slats Installation

The 1 1/2 x 1 1/2 shade slats are designed to be installed with 8 3/8" spacing between each slat.

Shade slats are designed to extend approximately 8 1/2" past the last rafter. Measurement includes the pre-installed pergola ends. Your goal is to ensure that all the shade slats overhang equally to the eye.

2

Install first shade slat adjacent to the top of the vinyl columns.

3

Install the rest of the shade slats at the 8 3/8" spacing.

4

Install one screw at each intersection of rafter and shade slat.

Suggestions for Additional Shade as Necessary

- Contact Eden Arbors regarding the possibility of purchasing an extra box of shade slats.
- White resin lattice in variety of shapes and sizes are available at your local lumberyard. Cut to size and fasten directly to the top of shade slats using stainless steel screws.
- In areas of extreme snow or wind load, do not use tight diamond privacy lattice.

